

SUPPLEMENT TO THE USER GUIDE

TAXIMETER PRIMUS MIRROR

Flat-rate fares for Paris and application of reservation supplements.

ATA ELECTRONICS

FRANCE EDITION — FEBRUARY 2016

TABLE OF CONTENTS

1.	Description of the Screen	3
2.	Overview	4
3.	Choosing between Tariff / Flat-Rate / Reservation	5
4.	For a Flat-Rate Journey	7
5.	For a Reservation	8
	Case 1 – The passenger is at the pick-up point	9
	Case 2 – The passenger is not yet at the pick-up point	10
6.	In the Case of a Detour	12
7.	Switching to "TO PAY" Position	13

1 – DESCRIPTION OF THE SCREEN

Zone	Description
① Push-buttons (BP1–BP5)	Five push-buttons used to control all meter functions.
② Status display area	Shows "TO PAY" and "TOTAL TO PAY" status messages.
③ Supplement amount display	Shows the total supplements amount in euros.
④ Price display area	Shows the current fare amount.
⑤ Tariff display area	Shows the active tariff (A, B, C or 1, 2, 3, 4 or R).

LEGEND	SYMBOL	ACTION
① Push-button	↑	Press the push-button.

2 – OVERVIEW

From 1 March 2016 at midnight, your **PRIMUS MIRROR** taximeter will operate in flat-rate mode for PARIS journeys and will apply reservation supplements. The operating mode is described in detail in this user guide.

MODE	DISPLAY	DESCRIPTION
STANDARD TARIFF	<i>Tariff A Tariff B Tariff C</i>	Standard metered fares — A, B and C tariffs as set by regulation.
FLAT-RATE FARE	<i>Flat 1: €50.00 — Roissy CDG ↔ Paris Right Bank Flat 2: €55.00 — Roissy CDG ↔ Paris Left Bank Flat 3: €30.00 — Orly ↔ Paris Left Bank Flat 4: €35.00 — Orly ↔ Paris Right Bank</i>	Fixed airport flat rates between Paris and CDG / Orly airports, in both directions.
RESERVATION	<i>Immediate reservation: €4.00 supplement Advance reservation: €7.00 supplement</i>	A reservation supplement is shown in the SUPPLEMENTS area. The fare does not increment during the approach.

3 – CHOOSING BETWEEN TARIFF / FLAT-RATE / RESERVATION

1 From the "FREE" position, press **BP1** to start a journey.

2 Press **BP1** repeatedly until the desired tariff / flat-rate / reservation is displayed.

The meter cycles through: Tariff A → Tariff B → Tariff C → Flat 1 → Flat 2 → Flat 3 → Flat 4 → Reservation (€4.00) → Reservation (€7.00) → (back to start)

3 Your selection is confirmed automatically.

In this example, immediate reservation was selected.

- *After selecting a tariff / flat-rate / reservation, it flashes until the vehicle has travelled a few tens of metres. The flashing indicates that it is still possible to change the tariff by pressing BP1. Once the tariff area stops flashing, the selection is confirmed and can no longer be changed.*

4 – FOR A FLAT-RATE JOURNEY

1 From the "FREE" position, press **BP1** to start a journey.

2 Press **BP1** until the desired flat-rate is displayed.

In this example, Flat 3 at €30.00 was selected.

3 The flat-rate amount remains the same for the entire duration of the journey.

TARIFF

SUPPLEMENTS

3

0.00 €

30.00

5 – FOR A RESERVATION

1 From the "FREE" position, press **BP1** to start a journey.

2 Press **BP1** until R €4.00 or R €7.00 is displayed.

In this example, an advance reservation was selected.

■ *The taximeter shows the reservation supplement amount (€4.00 or €7.00) and lamp A is lit. During the approach, the fare does not increment — neither time nor distance is counted.*

3 Your selection is confirmed automatically. It flashes until the vehicle has covered a few tens of metres.

Case 1 – The passenger IS at the pick-up point.

4 When your passenger arrives, press **BP1** until the desired tariff or flat-rate is displayed (A, B, C or 1, 2, 3, 4).

In this example, Flat 3 was selected with a pick-up charge of €30.00.

5 Your selection is confirmed automatically. It flashes until the vehicle has covered a few tens of metres.

Case 2 – The passenger is NOT yet at the pick-up point.

6 If your passenger is not at the pick-up point, you must switch to "WAITING" mode. Press **BP1** until the desired tariff is displayed with a pick-up charge of €0.00.

In this example, waiting in Tariff A with a pick-up charge of €0.00 was chosen.

7 The fare increments during the waiting period.

8 When the passenger arrives, press **BP1** until the desired tariff or flat-rate is displayed. The waiting amount is added to the pick-up charge.

In this example, Flat 3 at €30.00 was chosen, and €3.10 of waiting time was added, giving €33.10.

■ *At this stage, the "RESERVATION" position is no longer offered in the taximeter's intuitive navigation.*

9 Your selection is confirmed automatically. It flashes until the vehicle has covered a few tens of metres.

6 – IN THE CASE OF A DETOUR

- 1** In the case of a detour from flat-rate mode, press **BP1** until the applicable standard tariff is displayed, in order to exit flat-rate mode.

In this example, Tariff B was selected.

- 2** During the detour period, the meter runs and the cost of this leg is added to the flat-rate amount.

In this example, the detour cost is €2.00.

- 3** When the waiting or detour period ends, you have two options: - Switch to "TO PAY" if the service is complete. - Return to the originally chosen flat-rate by pressing **BP1**, if the service is not complete and the final destination has not changed.

In this example, we returned to the originally chosen flat-rate.

7 – SWITCHING TO "TO PAY" POSITION

1 To switch to "TO PAY" position, press **BP4**.

2 You are now in the "TO PAY" position.

TARIFF	SUPPLEMENTS
3	7.00 €
TO PAY	35.80